


Step 1: Connect the new pin solenoids using the diagram below:




Connecting a 24 VAC new pin solenoid to Steltronic Scoring





Connecting the 110 VAC new pin solenoid to Steltronic Scoring Systems



Step 2: Change the setting in Focus below.

Pinsetter Settings [2 items]

1 2

Basic **Advanced**

Hardware connection

- Off
- Ball Change
- A.P.S. on 1st Ball
- A.P.S. on 1st / 2nd Ball
- Gutter plus Strike
- Gutter plus Strike also for Foul

Pinsetter Type
Brunswick A1/A2 standard

Special cycles

- Automatic Foul Line Management
- Change ball if gutter or 7-10
- No tap and 10th frame respot
- Modified cycle for strike
- Wait for 2nd Ball signal before Respot Delay
- 1st Ball Cycle after photo
- 2nd Ball Cycle after photo
- Set Pins / Figures Enabled

Advanced

- Respot Delay (sec.) 2.0
- 1st Ball Extra Cycle Delay (sec.) 2.0
- 2nd to 1st Ball Change Delay (sec.) 2.0
- Extra cycle delay when foul and strike (sec.) 2.0
- Open Lane In Phase (sec.) 5
- Power Off Delay (sec.) 20
- Ball return power off delay (sec.) 10

Note

- Setting enabled for the items selected
- Setting disabled for the items selected
- The selected items do not have the same setting
- This background is for items who apply to the whole pair
- This background is for items who apply to the single lane

Cycle or Reset Pinsetter Set Pinsetter Set Pins and First Ball Set Pins and Second Ball Send to lane Send to lane and close

When the new pin solenoid is installed onto your detector, adjust it so that 1/4" of gap is obtained when the pinsetter is on 1st ball.

